



NOTES

- 1.) ALL STL. MEMBERS COATED W/ ZINC RICH EPOXY THEN FINISHED W/ POLYESTER POWDER COATING.
- 2.) 1/2" X 3 3/4" EXPANSION ANCHOR BOLTS PROVIDED.

WOOD OPTIONS

- 'C' & BTR. DOUGLAS FIR KD S4S EE
- IPE S4S EE
- OTHER _____



BENCH

DATE DRAWN : 10/03/13
 DRAWN BY : RDH
 DATE REV. : 12/31/15
 REV. BY : ESS

REV.
C

DRAWING
NUMBER

472-60/S-5

SHEET
1 OF 2

NOTES:

- 1.) DURING ASSEMBLY PROCEDURE;
DO NOT COMPLETELY TIGHTEN HARDWARE.
- 2.) THE ACTUAL PARTS WILL NOT BE NUMBERED.
NUMBERS ONLY APPLY TO DRAWING.
- 3.) UPON COMPLETION OF ASSEMBLY SQUARE
ALL COMPONENTS THEN TIGHTEN ALL HARDWARE.
- 4.) MOUNT AND ANCHOR AS SPECIFIED.

TOOLS REQ'D

- 3/16" ALLEN WRENCH
- 1/4" ALLEN WRENCH
- 1/2" WRENCH
- 3/4" WRENCH
- 9/16" WRENCH
- 1/2" MASONRY DRILL BIT
- DRILL

PARTS LIST

ITEM	QTY	PART NO	DESCRIPTION
1	2	0-472-00-01	STL SUPPORT
2	1	0-472-60-03	71" INT'R SLAT, WOOD
3	1	0-472-60-04	71" INT'R SLAT, WOOD
4	4	0-472-60-05	2" X 6" X 71" EDGE PROFILE SLAT, WOOD
5	1	0-472-60-07	STL SEAT FRAME
6	1	0-472-60-08	STL BACKREST FRAME
7	4	1-11-003	3/8" X 1 1/2" SS CGE BOLT
8	4	1-12-133	3/8" X 3/4" SS BTN SKT HD CAP SCR
9	14	1-13-023	5/16" X 1 1/2" SS BTN SKT HD LAG
10	4	1-13-038	5/16" X 2" SS HEX HD LAG SCR
11	18	1-22-017	5/16" SS FLAT WASHER
11	4	1-20-007	3/8" SS NYLON LOCKNUT
12	4	1-22-024	3/8" SS FLAT WASHER

KITS PROVIDED

ITEM	QTY	PART NO	DESCRIPTION
13	1	K-ANC0860-4	1/2" X 3 3/4" SS ANCHOR KIT (4PC)
14	1	K-BC0612-4	3/8" CAP HARDWARE KIT (4PC)
15	1	K-BL0524-14	5/16" LAG HARDWARE KIT (14PC)
16	2	K-CG0624-2L	3/8" CGE BOLT HARDWARE KIT W/ LOCK NUTS (2PC)
17	2	K-HL0532-2	5/16" LAG HARDWARE KIT (2PC)

1

ATTACH REAR SEAT SLAT ONLY TO SEAT FRAME.
DO NOT ATTACH FRONT TWO SLATS OF SEAT.
ATTACH SLATS TO BACKREST FRAME.

2

ATTACH SUPPORTS TO SEAT FRAME. INSERT HARDWARE THROUGH SUPPORT INTO TAPPED HOLES IN FRAME.

3

ATTACH SUPPORTS TO BACKREST FRAME.

4

ATTACH FRONT TWO REMAINING SEAT SLATS.